

# Work Permit # DRL-2011-014 Work Order # \_\_\_\_ Job# \_\_\_\_ Activity# \_\_\_\_

Work requester fills out this section.	☐ Standin	g Work Permit		<u> </u>					
Requester: Don Lynch	Date: 6/29/2011	Ext.: 2253							
Other Contact person (if different from	ı requester): Carter Biggs		Ext.: 7515	15					
Work Control Coordinator: Don Lynch	n	Start Date6/29/2011	Est. End Date: 12/1/2	20110					
Brief Description of Work: PC1 East	FEM Repair								
Building: 1008	Room: IR	Equipment: PC1 East	Service Provider: PH	ENIX techs & PC experts					
VCC, Requester/Designee, Service Pro	vider, and ES&H (as necessary) fill	I out this section or attach anal	ysis	•					
ES&H ANALYSIS									
Radiation Concerns	None ☐ Activation	☐ Airborne	☐ Contamination	Radiation					
Radiation Generating Devices:	☐ Radiography [	☐Moisture Density Gauges	Soil Density Gauges	☐X-ray Equipment					
☐ Special nuclear materials involv	red, notify Isotope Special Materials C	Group	☐ Fissionable materials inv	volved, notify Laboratory Criticality Officer					
Safety Concerns	☐ None	☐ Ergonomics	☐ Transport of Haz/Rad Ma	aterial					
Adding/Demoving Wells or Deep	Confined Space*	☐ Explosives	☐ Lead*	☐ Penetrating Fire Walls					
Adding/Removing Walls or Room	Corrosive	☐ Flammable	☐ Magnetic Field*	☐ Pressurized Systems					
☐ Asbestos*	☐ Cryogenic	☐ Fumes/Mist/Dust*		☐ Rigging/Critical Lift					
☐ Beryllium*	☐ Electrical	☐ Heat/Cold Stress	☐ Noise*	☐ Toxic Materials*					
☐ Biohazard*		☐ Hydraulic	☐ Non-ionizing Radiation*	☐ Vacuum					
☐ Chemicals*	☐ Excavation	☐ Lasers*	☐ Oxygen Deficiency*	☐ Other					
* Does this work require medical cle	arance or surveillance from the Occu	pational Medicine Clinic?   Ye	es 🔀 No	•					
Environmental Concerns				Work impacts Environmental Permit No.					
Atmospheric Discharges (rad/no	on-rad)	☐ Land Use	Soil	☐ Waste-Mixed					
_ , , ,			Activation/contamination						
Chemical or Rad Material Stora	☐ Chemical or Rad Material Storage or Use		☐ Waste-Clean	☐ Waste-Radioactive					
☐ Cesspools (UIC)	Cesspools (UIC)		☐ Waste-Hazardous	☐ Waste-Regulated Medical					
High water/power consumption			☐ Waste-Industrial	Underground Duct/Piping					
Waste disposition by:	_ • • •		- Waste-Illudstilai	Other					
Pollution Prevention (P2)/Waste N	Ainimization Opportunity:	None    Yes     Yes     None    Yes     None    Yes     None    None		Other					
FACILITY CONCERNS	None None	None 103							
TAGILITI CONCLINIC	☐ Electrical Noise	☐ Potential to Cause a	 Falso Δlarm	Vibrations					
☐ Access/Egress Limitations	☐ Impacts Facility Use A	_	Temperature Change	Other					
☐ Configuration Control			Utility Interruptions						
WORK CONTROLS	Waintenance Work on	ventilation dystems	Culty Interruptions						
Work CONTROLS  Work Practices									
None	☐ Exhaust Ventilation		☐ Spill Containment	Security (see Instruction Sheet)					
		Posting/Warning	<del>  -</del> ·						
Back-up Person/Watch     Back-up Pers	☐ HP Coverage	Signs	☐ Time Limitation	☐ Other					
☐ Barricades	☐ IH Survey	☐ Scaffolding-requires	☐ Warning Alarm (i.e. "high level")						
	inspection warning Alarm (i.e. "nign level")								
Protective Equipment									
None	☐ Ear Plugs	Gloves	Lab Coat						
☐ Coveralls	☐ Ear Muffs	☐ Goggles	☐ Respirator	☐ Safety Harness					
☐ Disposable Clothing	☐ Face Shield	Hard Hat	☐ Shoe Covers	Safety Other					
Permits Required (Permits must be	valid when job is scheduled )			Glioco					
None	Cutting/Welding	☐ Impair Fire Protection	Systems						
☐ Concrete/Masonry Penetration	☐ Digging/Core Drilling		ad Work Permit-RWP No						
Confined Space Entry	☐ Electrical Working Hot								
Dosimetry/Monitoring		Culoi							
None None	☐ Heat Stress Monitor	Real Time Monitor	☐ TLD						
		Self-reading Pencil	+=						
☐ Air Effluent	☐ Noise Survey/Dosimete	er Dosimeter  ☐ Self-reading Digital	☐ Waste Characterization						
Ground Water	☐ Ground Water ☐ O₂/Combustible Gas		Other Check O2 level prior to entry						
Ground Water		Dosimeter Contract Tube / Cites	The States Officer OZ level prior to cittly						
☐ Liquid Effluent	☐ Passive Vapor Monitor	Sorbent Tube/Filter							
Training Requirements (List below	raining Requirements (List below specific training requirements)								
CA –Collider User, PHENIX Awaren									
If using the permit when all hazard ratings are low only the follow									
Based on analysis above, the Walkdown Team determines the risk, complexity, and		complexity, and coordination	need to sign: ( Although allowed, there is no need to use back of						
ratings below:			form)						
ES&H Risk Level:		v	WCC:	Date:					
Complexity Level:			Service Provider:	Date:					
Work Coordination:		te  High	Authorization to start	Date:					
			(Departmental Sun/WCC/Des	signee)					

	Work Plan (procedures, timing, equipment, and personnel availability need to be addressed): See Attached Work Plan										
	Special Working Conditions Required: None										
	Operational Limits Imposed: Modification work limited to lower octants easily reachable when standing on lower magnet superstructure.										
	Post Work Testing Required: No										
	Job Safety Analysis Required: ☐ Yes ☒ No			Walkdown Required: ☑ Yes ☐ No							
	Reviewed by: Primary Reviewer will determine the size of the review team and the other signatures required based on hazards and job complexity. Primary Reviewer signature meather that the hazards and risks that could impact ES&H have been identified and will be controlled according to BNL requirements.										
	<u>Title</u>	Name (print)	<u>Signature</u>		Life #		<u>Date</u>				
	Primary Reviewer										
	ES&H Professional										
	Other										
	Other										
	Work Control Coordinator										
	Service Provider										
		Review Done:  in series	□ team								
		Treview Belle.   In series	L team								
4. Jol	site personnel fill out this section.										
	Note: Signature indicates personnel performing work have read and understand the hazards and permit requirements (including any attachments).										
	ob Supervisor:			Contractor Supervisor:							
	Workers:	Life#:		Workers :		Life#:					
	Workers are encouraged to provide feed	dback on ES&H concerns or on	ideas for improved job	work flow. Use t	eedback form or space b	elow.					
5. De	partmental Job Supervisor, Work Contr	rol Coordinator/Designee									
	Conditions are appropriate to start work: (Permit has been reviewed, work controls are in place and site is ready for job.)										
	Name:	ame: Signature:		Life#: Dai		Date:	ate:				
6. De	partmental Job Supervisor, Work Requ	ester/Designee determines if	Post Job Review is r	equired. $\square$ Ye	s □ No						
	Post Job Review (Fill in names of review										
	Name:	lame: Signature:		Life#:		Date:	Date:				
	Name:	Signature:		Life#:		Date:					
7. Wo	rker provides feedback.  Worker Feedback (use attached sheets	as necessary)									
	a) WCM/WCC: Is any feedback require										
	b) Workers: Are there better methods or safer ways to perform this job in the future?   Yes   No										
8. Clo	8. Closeout: Work Control Coordinator (authorizing dept.) checks quality of completed permit and ensures the work site is left in an acceptable condition. (WCC can delegate										
	up of work area to work supervisor)		•			1					
	Name:	Signature:		Life#:		Date:					
	Comments:										

# PC1E Toubleshooting in the PHENIX Experimental Hall (bldg. 1008).

# **Problem**

A malfunctioning front end module (FEM) in the PHENIX east Pad Chamber 1 at the bottom end is not functioning properly. (see figure 1) The faults can be addressed by troubleshooting the offending FEM board and connectors which are accessible by arranging to get at it from a step ladder or fixed ladder. The DC/PC1 module may need to be opened a few inches to access the faulty components.

The procedures described below have been used successfully in the past to trouble shoot and repair similarly malfunctioning components of the PC1 detector subsystem. The procedure involves use of a fixed ladder secured to the body of the CM.

# Work Plan

This work is to be done by fully trained and experienced personnel (PHENIX mechanical and electrical technicians and PC1 expert scientists) during the 2011 maintenance shutdown.

REF: PP-2.5.5.1-01 "Moving the Central Magnet and Detector Carriages in the PHENIX IR"

#### 1. Preparation for repairs

- persons performing this work shall have PHENIX Awareness training, CA access training and BNL ladder training.
- Move the east carriage to its open (east-most) position and secure it at the position in accordance with PHENIX standard operating procedures (PP-2.5.5.1-01).
- Ensure that power to the DC & PC1 electronics are secured and that the CM power key is locked out of use.
- A watch person must be present at all times when a person is on the ladders
- Test, reseat, reset, etc. the connection between the faulty module and its cables as necessary to determine the cause of malfunctioning.
- Effect appropriate repairs as necessary. If repairs exceed simple remove/replace, reseat or reset efforts (see PHENIX Awareness Training) such that additional planning is

required, restore all equipment to pre-troubleshooting configuration and consult with PHENIX work control coordinator(s) before attempting more complicated repair efforts.

# 2. Open the DC/PC1 East

Should access to the module/cable/connector prove to be impossible without moving the DC/PC1 east assembly, the assembly may be moved a few inches, up to 12 inches, as achievable without disconnecting any cables, wires hoses or tubing, except for rigid tubing or piping easily disconnected from the bottom end of the DC. This is accomplished as follows:


- remove rigid tubing or piping easily disconnected from the bottom end of the DC.
- install a C-clamp stop to prevent the DC/PC1 assembly from moving more than 3 inches west from its run position.
- remove the clamp securing the DC east in the run position.
- put the DC thrust bar into the retaining slot.
- carefully push the DC translation thrust bar westward to slowly move the DC/PC1 approximately 1-12 inches as allowed by cabling, hose and tubing slack. Take care not to damage any cables, hoses and/or tubes.
- install the open position retaining clamp

#### 4. Work conclusion


- remove ladders
- remove the clamp securing the DC in the open position.
- carefully push the DC translation thrust bar eastward to slowly move the DC/PC1 a few inches until it contacts its run position stops.
- -re-install the run position retaining clamp
- remove the east stop C-clamp
- remove the DC translation thrust bar from the thrust bar retaining slots and return it to storage for future use.
- -check all wiring and piping to make sure none were damaged during the DC/PC1 moves. Effect repairs if necessary.

- re-install any rigid tubing/piping as necessary.
- Close out work permit recording any useful feedback concerning the work performed.

# Figure 1: FEM repairs needed on PC1 West



East Carriage with DC/PC1 in run position



East Carriage with DC/PC1 in open position

Figure 2: Drift Chamber Translation

